


# Second Position Down. TIP

```
329      SetDO(douMainArmGrip,OFF)
330      END_IF
331      IF bSimpleFlowChart = FALSE THEN
332          //170725 add WJM
333          Increment(palletcountY)
334          IF pallet1.numberOfParts[1] = palletcountY THEN
335              palletcountX := palletcountX + 1
336              palletcountY := 0
337          END_IF
338          IF pallet1.numberOfParts[0] = palletcountX THEN
339              palletcountZ := palletcountZ + 1
340              palletcountX := 0
341          END_IF
342          IF pallet1.numberOfParts[2] = palletcountZ THEN
343              palletcountZ := 0
344          END_IF
345          Increment(palletcount)
346      END_IF
347  END_IF
```

Line 331's IF statement represents a Simple Flow Chart, which indicates Dry Cycle Mode. In other words, when Dry Cycle is turned on, this condition is evaluated as false and skipped.

Therefore, it is recommended to change the condition to IF TRUE THEN to ensure that it is always evaluated as true. However, it is recommended to keep the existing Line 331 code commented out for future reference.



```
329      SetDO(douMainArmGrip,OFF)
330      END_IF
331      //IF bSimpleFlowChart = FALSE THEN
332      IF TRUE THEN
333          //170725 add WJM
334          Increment(palletcountY)
335          IF pallet1.numberOfParts[1] = palletcountY THEN
336              palletcountX := palletcountX + 1
337              palletcountY := 0
338          END_IF
339          IF pallet1.numberOfParts[0] = palletcountX THEN
340              palletcountZ := palletcountZ + 1
341              palletcountX := 0
342          END_IF
343          IF pallet1.numberOfParts[2] = palletcountZ THEN
344              palletcountZ := 0
345          END_IF
346          Increment(palletcount)
347      END_IF
348  END_IF
```